



#3030
Pop Mop™
Pro

pop mop™ pro

Instructions

To remove the used microfiber pad from you new **Pop Mop™ Pro** follow these steps:




Step 1

To remove the dirty pad after cleaning with your **Pop Mop™ Pro**, hold the mop straight up and down, so the **plastic housing (A)** is aligned with the **4 plastic posts (B)** on the mop head.

Step 2

Then push down on the plastic housing to pop off the dirty mop pad.



7171 Telegraph Road
Montebello, CA 90640 | USA

w. delamo-mfg.com
e. delamo@delamo-mfg.com
t. 888/711.8011
t. 323/936.3566
f. 323/936.3567

